

**Installation Instructions** 

**RETROFIT KIT to assist in the installation of a Bendix**<sup>®</sup> **BA-922**<sup>®</sup> **compressor for DDC S50 engines (typically transit bus applications).** These instructions assist in identifying the components included in this kit. For installation, please use the full Installation Instructions and Cautions included in the (required) Compressor Fittings Kit.

Kit Contents:			Mounting Bracket
Description	Quantity	Key	
ECM Mounting Bracket (5016021) Bolt, M8 ECN bracket to block (M8-1.5, 20mm) (5015754) Bolt, M10 Rear support bracket to block (M10-1.5, 20mm) (5007856)	3	. not showr	

S-1450 © 2005 Bendix Commercial Vehicle Systems LLC 102005 Printed in U.S.A. All rights reserved.



**RETROFIT KIT to assist in the installation of a Bendix® BA-922® compressor for DDC S50 engines (typically transit bus applications).** These instructions assist in identifying the components included in this kit. For installation, please use the full Installation Instructions and Cautions included in the (required) Compressor Fittings Kit.

Kit Contents: Description	Quantity	Key	Mounting Bracket
ECM Mounting Bracket (5016021) Bolt, M8 ECN bracket to block (M8-1.5, 20mm) (5015754) Bolt, M10 Rear support bracket to block (M10-1.5, 20mm) (5007856)	3	not show	

S-1450 © 2005 Bendix Commercial Vehicle Systems LLC 102005 Printed in U.S.A. All rights reserved.



Installation Instructions

KIT PC. No. 5016250

**RETROFIT KIT to assist in the installation of a Bendix® BA-922® compressor for DDC S50 engines (typically transit bus applications).** These instructions assist in identifying the components included in this kit. For installation, please use the full Installation Instructions and Cautions included in the (required) Compressor Fittings Kit.

Kit Contents: Description ECM Mounting Bracket (5016021) Bolt, M8 ECN bracket to block (M8-1.5, 20mm) (5015754) Bolt, M10 Rear support bracket to block (M10-1.5, 20mm) (5007856)	3 not shown (P)
	ø