



Slack Adjuster (Manual)



Inclination Angle
(Body Angle)
CCW = Negative

Arm Length 1
Arm Length 2
Arm Length 3

Spline Diameter - Teeth

0°

Lube Fitting Position
CW = Positive

Product Dimensions

