

## AutoVue® Camera Replacement Guide

This camera replacement kit consists of two parts:

- Camera
- Processor

Please ensure that both the camera and the processor are replaced when replacing the faulty camera.

## **A** WARNING:

Failure to replace both the camera and the processor will result in lost functionality.

▲IMPORTANT: The 3G Bendix<sup>™</sup> AutoVue<sup>®</sup> LDW (Lane Departure Warning) processor is programmed with Bendix<sup>™</sup> SafetyDirect<sup>®</sup> functionality enabled. SafetyDirect events and applicable video will be recorded on the processor.

For technical support, call the Bendix Tech Team at: 1-800-AIR-BRAKE (1-800-247-2725) option 2, or visit bendix.com.