

Subject: Troubleshooting Bendix® ABS, ATC & ESP® EC-80™ Controllers

The family of Bendix® ABS, ATC & ESP® EC-80™ Controllers have been in production since the final quarter of 2014. These Controllers communicate using the J1939 bus only.

To troubleshoot a Bendix EC-80 Controller, use the latest version of the Bendix® ACom® Diagnostic Software (version 6.7.2.5 or higher), available as a free download from the Bendix web site (www.bendix.com).

If you wish to verify if your current Bendix ACom Diagnostic Software is version 6.7.2.5 or higher, simply:

1. Launch the Bendix ACom Diagnostic Software.
2. Select the "Help" tab, then select "About".
3. The current software version will be displayed.
4. If needed, visit www.bendix.com for the latest download.

When troubleshooting with a Bendix® Remote Diagnostic Unit (RDU™), use the latest release of the tool, part number K101596N001. Please note that earlier versions of the Bendix RDU tool are not compatible with the Bendix EC-80 Controllers.

NOTE: Be sure to use Bendix ACom Diagnostic Software version 6.8.3.2 or later when troubleshooting Cummins® Inline adapters 5 and 6.

Reference Documents:

For Bendix® ABS/ATC EC-80™ Controllers download/order Bendix Service Data Sheet SD-13-4983.

For Bendix® ESP EC-80™ Controllers download/order SD-13-4986.

Downloads: Go to the Document Library on www.bendix.com for Service Data Sheets.

Printed Copies: Literature can be ordered directly from the on-line Bendix Literature Center. To register or to access your existing account, visit www.bendix.com and click on the "Marketing Center" tab at the top of the [bendix.com](http://www.bendix.com) homepage, or use the link on www.foundationbrakes.com.



FIGURE 1 - THE FAMILY OF BENDIX® EC-80™ CONTROLLERS




FIGURE 2 - BENDIX® ACOM® DIAGNOSTIC SOFTWARE & THE BENDIX® REMOTE DIAGNOSTIC UNIT (RDU™)

Log-on and Learn from the Best

On-line training that's available when you are —24/7/365.

Visit www.brake-school.com.

