

Group 01: Compressors, Flange Mount				Group 1A: CAT® Flange Mount				Group 1B: Cummins® Flange Mount			Group 1C: DDC® Flange Mount									
CLASS 26	CLASS 14	CLASS 05	CLASS 06	CLASS 1A	CLASS 2A	CLASS 1B	CLASS 2B	CLASS 1C	CLASS 2C	CLASS 1C	CLASS 2C	CLASS 1C	CLASS 2C	CLASS 1C	CLASS 2C					
Group 1D: DDC Flange Mount			Group 1E: Cummins® Flange Mount			Group 1F: Mack® Flange Mount			Group 1G: Navistar® Flange Mount			1H: Volvo Flange Mount		Group 1I: Base Mount	Group 1J: DDC Flange Mount	Group 1K: CAT Flange Mount				
CLASS 1D	CLASS 2D	CLASS 1E	CLASS 2E	CLASS 1F	CLASS 2F	CLASS 1G	CLASS 2G	CLASS 1H	CLASS 2H	CLASS 60	CLASS 2J, 3J	CLASS 2K								
Group 1L: DDC Flange Mount	Group 1M: DDC Flange Mount	Group 1N: Deere/CAT Flange Mount		Group 1P: CAT Flange Mount	Group 1S: DDC Flange Mount	Group 1T: DDC Flange Mount	Group 1U: SAE B Flange Mount	Group 1V: Navistar Flange Mount	Group 1W: Navistar Flange Mount	Group 1X: Navistar Flange Mount	Group 1Y: Volvo Flange Mount	Group 12: Old-Style Base-Mount								
CLASS 1L	CLASS 1M	CLASS 1N	CLASS 1P	CLASS 1S	CLASS 1T	CLASS 1U	CLASS 1V	CLASS 1W	CLASS 1X	CLASS 1Y	CLASS 59	CLASS 62	CLASS 61							
Group 13: Old-Style Base-Mount								Group 14: CAT/DDC Flange Mount		Group 4	Group 6	Group 9	Group 9A	Group 9B	Group 9C	Group 9D	Group 26			
Engine-Lubed or Water-Cooled				Self-Lubed or Air-Cooled				CLASS 97	CLASS 13	CLASS 66	CLASS 17	CLASS 68	CLASS 29	CLASS 79	CLASS 96	CLASS 9C	CLASS 9D	CLASS 63		
CLASS 02	CLASS 01	CLASS 30	CLASS 56	CLASS 57	CLASS 55	CLASS 64	CLASS 13	CLASS 66	CLASS 17	CLASS 68	CLASS 29	CLASS 79	CLASS 96	CLASS 9C	CLASS 9D	CLASS 63				
Group 3			Group 5		Group 16: Dash Valves							Group 17: Limiting and Quick Release Valves					Group 25			
CLASS 41	CLASS 41	CLASS 41	CLASS 16	CLASS 36	CLASS 37	CLASS 37	CLASS 36	CLASS 37	CLASS 37	CLASS 37	CLASS 37	CLASS 37	CLASS 43	CLASS 39	CLASS 39	CLASS 43	CLASS 38	CLASS 40	CLASS 69	CLASS 40
Group 27	Group 28				Group 31			Group 32	Group 33	Group 34	Group 35	Group 36		Group 37			Group 38	Group 70	Group 73	
CLASS 19	CLASS 33	CLASS 08	CLASS 09	CLASS 75	CLASS 31	CLASS 32	CLASS 32	CLASS 72	CLASS 35	CLASS 34	CLASS 70	CLASS 12	CLASS 25	CLASS 20	CLASS 20	CLASS 22	CLASS 76	CLASS 73	CLASS 10	
Group SA	Group SC	Group SD	Group SE	Group SF	Group SG	Group SH	Group SK	Group SM	Group SN	Group SV	Group SW	Group SX	Group 90							
CLASS F1	CLASS F2	CLASS F3	CLASS G6	CLASS G7	CLASS F6	CLASS F7 & F8	CLASS E1	CLASS F4	CLASS F5	CLASS E6	CLASS E7	CLASS E8	CLASS J2	CLASS J3 & J4						