


UP2DATE

TRUCKSERVICES ACTUATOR MAINTENANCE GAUGE

TruckServices, the Aftermarket brand of Knorr-Bremse, supplies vehicle owners, fleets, workshops and distributors with high quality products and service solutions for commercial vehicles of all kind of ages. That is how TruckServices ensures that every vehicle is back on the road quickly and in perfect condition. As an additional service we are introducing our "Actuator Maintenance Gauge".

At a glance

- › Supports maintenance process and leads to quick service decisions
- › Reduction of downtime
- › Enables a quick and easy check of the height of the actuator's seal and push rod
- › Cost efficiency: service kits can be used in a more rapid manner
- › Ensures orientation of actuator corresponds exactly with original installation



The Actuator Maintenance Gauge was developed by TruckServices to support the maintenance process of the actuator. By following a few simple steps, the gauge enables an easy test of the actuator's interface seal to Knorr-Bremse air disc brakes and also supports the inspection of the height of the push rod. Furthermore, during maintenance with an original Knorr-Bremse actuator kit, or when fully replacing a spring brake with a rationalized unit, the gauge helps the operator to correctly re-assemble the components.

The Actuator Maintenance Gauge is now available: **K108806K50**

TRUCKSERVICES



EVERY VEHICLE TELLS ITS STORY.
KEEP IT RUNNING

Up-to-date information on our products can be
found on our website www.knorr-bremsecvs.com



Knorr-Bremse Group

Knorr-Bremse Systems for Commercial Vehicles

Moosacher Strasse 80 | 80809 Munich | Germany
Tél: +49 89 3547-0 | Fax: +49 89 3547-2767
WWW.KNORR-BREMSECVS.COM

Note

All information is subject to change. A printed version of this document may therefore not correspond to the latest revision. To obtain the latest version, please visit our website www.knorr-bremsecvs.com or contact a Knorr-Bremse representative in your area.

If service work is carried out on a vehicle based on information provided herein, it is the responsibility of the workshop to ensure the vehicle is fully tested and in full functional order before the vehicle is returned into service. Knorr-Bremse accepts no liability for problems caused as a result of appropriate tests not being carried out.

Copyright © Knorr-Bremse AG

All rights reserved, including industrial property rights applications. Knorr-Bremse AG retains any power of disposal, such as for copying and transferring.

Disclaimer

The information contained herein is intended for the exclusive use of trained persons within the commercial vehicle industry, and must not be passed on to any third party. All recommendations regarding products and their servicing or usage are with reference to Knorr-Bremse products and should not be considered applicable to products from other manufacturers. This information does not purport to be all-inclusive and no responsibility is assumed as a result of its use. We cannot accept any liability nor offer any guarantee regarding data accuracy, completeness or timeliness. The information does not represent any guarantee or ensured characteristics of the Products or Systems described. No liability can be accepted based on the information, its use, recommendations or advice provided. In no event may we be held liable for any damage or loss except in the case of wilful intent or gross negligence on our part, or if any mandatory legal provisions apply. This disclaimer is an English translation of a German text, which should be referred to for all legal purposes. Any legal disputes arising from the use of this information shall be subject to German law.